#26053 PopSockets™ PopWallet+ for Magnetic Wireless Charging



NEW!

POPSOCKETS

Regular Pricing

25	75	150	225	300	
$34.87	$32.55	$27.90	$27.12	$24.42	5C

Highlights

- MagSafe® Compatible Phone Wallet And Grip That Magnetically Connects To The Back Of Your Phone Or MagSafe® Case
- Built-In Grip Doubles As A Stand
- Offers A Sleek, Secure Way To Carry Cards On Your Phone
- Adheres To Back Of Your Phone Or Device Magnetically
- Slides Off Easily For Wireless Charging
- Sticks Flat To The Back Of Your Device
- Extend PopGrip To Use As A Media Stand And Phone Grip
- Makes Texting With One Hand And Snapping Photos Easier
- Easily Hold Or Handle Phone Better
- Hands-Free Way To Watch Videos Or Enjoy Your Favorite Media
- Holds Up To 3 Credit Cards Or 6 Business Cards
- Perfect For Carrying Identification, Room Keys, Cash Or Credit Cards
- Includes PopWallet+ And Adhesive Magnetic Ring Adapter For Non-MagSafe® Devices
- The PopSockets name and PopSockets trademarks are the property of PopSockets LLC, registered in the U.S. and other countries
- MagSafe is a trademark of Apple Inc., registered in the U.S. and other countries.

Packaging Details

Quantity per Box	Box Weight	Box Length	Box Width	Box Height
250	25 lbs.	18"	12"	8"

Dimensions are in inches. Weight is in pounds.

Description

- COLORS AVAILABLE: Black or White, both with Black.
- IMPRINT COLORS: Digital Imprint. Standard Pricing Includes One Color Imprint in One Location.
- APPROXIMATE SIZE: 2 ¼" W x 3 ½" H x ½" D
- IMPRINT AREA AND METHOD: On PopGrip: 1 3/10" Diameter
- SET UP CHARGE: One Color: $56.25(G) • Full Color: $80.00(G) • Re-Orders: Set up charges also apply to re-orders.
- MULTI-COLOR IMPRINT: Standard Pricing Includes 1 Color Digital Imprint. For 2-4 Color Imprints, Full Color Set Up Applies.
- LEAD TIME: 3-5 business days after proof approval.
- PACKAGING: Bag.
- FOB ZIP: WA, 98134
- PLEASE NOTE: For the best results, use it with a MagSafe® phone case. If you don't have a MagSafe® case, use the included Adapter Ring, which has an adhesive that should adhere to most cases, except silicone, textured cases, and cases with certain coatings. To avoid demagnetizing, cards must be removed from the wallet prior to charging with a Qi wireless charger. Instructions included. Powered by iClick. *Item contains one or more small magnets. Keep out of reach of children. See general information for details.